




QUICK START GUIDE



1. Mini DIN jack for the AV input
2. Female VGA port (HD15) for video output
3. AV output connector (Green: Y, Blue: Pb, Red (bottom): Pr, Yellow: Digital Coax Audio, White: Left Analog Audio, Red (top): Right Analog Audio outputs)
4. TOSLINK optical digital audio connector
5. HSYNC polarity jumper (1-2 for (-), 2-3 for (+) **)
6. VSYNC polarity jumper (1-2 for (-), 2-3 for (+) **)
7. RGB output mode switch (bottom position for RGBHV, top for RGBS)
8. LPF: internal HD low-pass filters (1-2 off, 2-3 on)
9. Power led

** For some resolutions, jumpers can be changed for proper displaying

