



QUICK START GUIDE



- 1. Power supply input socket (Red: 5v, Yellow: 12v, Black: Ground)
- 2. Audio output mode pushbutton (Line in or attenuated audio)
- 3. Scart output for audio/video with auto switching RGB mode
- 4. Jumper selection for Mono or MVS (Stereo) Audio mode
- 5. Headphone jack for Line input (also can be used as line out when the line in terminal is wired)
- **6.** Line input terminal for wiring the audio output from the mainboard directly (may require stereo mod)
- 7. Player 1 Controller input(for pinout check next diagram)
- 8. Player 2 Controller input(for pinout check next diagram)
- 9. Service mode switch
- 10. Test mode switch
- **11.** Coin switch
- 12. LPF (low pass filter) 1,2 On, 2.3 Off
- 13. Power led
- 14. 5 volts (Voltmeter) display



looking at the male DB15 port on a SHOGUN